

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5





FIG. 6

AREA TABLE

AREA	CAMERA ID	CAMERA PARAMETER (P, T, Z)
80	90	(0, 10, 2)
	92	(-45, -10, 4)
81	92	(0, 25, 8)
	91	(60, 30, 3)
82	93	(-10, 0, 2)
90	91	(-8, 0, 1)
	92	(-10, 10, 3)


005260 " 0EE69960

FIG. 7



005260" 0EE63950

FIG. 8



005260" 0EE69360



FIG. 9

FIG. 10

005260" 02259960

FIG. 11A

FIXED INFORMATION

CAMERA NUMBER	CAMERA NAME	HOST NAME	INSTALLATION POSITION	INITIAL DIRECTION	MAXIMUM ZOOM RATIO	MAXIMUM FIELD ANGLE	PANNABLE DIRECTION
1	camera1	host1	(150, 11)	180	8.0	120	(120, 240)
2	camera2						

FIG. 11B

VARIABLE INFORMATION

CAMERA NUMBER	ZOOM RATIO	VIDEO FIELD ANGLE	CURRENT IMAGE SENSING DIRECTION	IMAGE SENSING RANGE	DURING CAMERA CONTROL
1	3.0	40	145	(125, 165)	Y
2					N

FIG. 12




FIG. 13

